





## Sub group - II



Insoluble in  $\text{CH}_3\text{COOH}$

★ Test with  $H_2O_2$  in presence of organic solvent +





Note  $\Rightarrow$  In presence of aq. solvent  
 Reaction is non redox  
 While in absence of reaction is Redox




$\text{CrO}_5$  is Blue Coloured Compound and it's blue Coloured

Fades away in aqueous solution due to



presence of two three memb. Ring

but in presence of organic solvent it's Blue Coloured remains same





Note  $\Rightarrow$  Now-a-days  $(C_5H_{11}OH)$  amyl alc. is used  
in place of dimethyl ether  
because it is highly inflammable





$\text{MnO}_4^-$   $\Rightarrow$  all are soluble






- flame test
- Borax bead test
- phosphate bead test
- Sodium carbonate bead test
- Cobalt nitrate charcoal cavity test.



## Flame test




Pt wire use for flame test  
because it is inert if

Pt wire not available then  
Nichrome wire use

First Pt wire dipped in conc. HCl and further  
brought near to the given salt

So that given salt is converted into the  
corresponding chloride salt  
because chloride salts are more volatile than  
other salt.



Golden yellow colour

Li = Carmine Red / Crimson Red

Na = Golden yellow

K = Lilac (pale violet)

Rb = Reddish violet

Cs = Blue

Ca = Brick Red

Sr = Crimson Red


Ba = Apple green

Pb | Sn | Bi | Sb  $\Rightarrow$  Blue but

Pt wire anode

Note  $\Rightarrow$  Be and Mg  
do not give  
flame test due to  
their high IE

Sometime K and Na present together  
do golden yellow colour of sodium  
exist long time in to the flame  
and lilac colour K is not  
appear, in this condition  
cobalt glass use





$\text{BaCl}_2$   $\text{CaCl}_2$   $\text{SrCl}_2$   
less volatile  
than  $\text{KCl}$


(A)  $\text{KCl}$

(B)  $\text{BaCl}_2$  /  $\text{CaCl}_2$  /  $\text{SrCl}_2$



(P) fusion zone

(Q) lower oxidizing flame

# Borax bead test



transparent glass bead



Copper metaborate (Blue col. in oxidising flame)

Ortho Borate salt



in Reducing flame

Co — Blue colour

Cr — green

Mn = Amethyst

(light purple / light pink)