







Redox Reaction








Redox Reaction based on Reducing Prop. of SO_2 gas







Comprop. Reaction





Test with sodium nitroprusside








based on oxidising prop.




Devarda alloy (Zn/Cu/Al) with strong alkaline solution






Test with Zinc nitroprusside



Note \Rightarrow S^{2-} and $\text{S}_2\text{O}_3^{2-}$ ion interfere
they can be removed by
using HgCl_2



moist SO_2 gas

Red colour compound
with unknown composition.

Shiff Reagent / magenta reagent / fuchsin reagent

When SO_2 / SO_3^{2-} solution
added in Shiff reagent
then light pink colour disappears

Note $\Rightarrow \text{CO}_2$ does not interfere but NO_2 does


$\Rightarrow \text{S}_2\text{O}_3^{2-}$ does not interfere but

S^{2-} , polysulphide and alkali metal
Interfere


HSO_3^- = all are soluble



Test with H_2O_2




Distin. b/w SO_3^{2-} and HSO_3^-



if this solution turns Blue litmus to Red then HSO_3^- present.

$\text{CO}_3^{-2} / \text{SO}_3^{-2}$ distinction

dil HCl



S^{2-} = all are Insoluble
except IA/IIA and $(NH_4)_2S$

① Test with acid





Rotten egg smell

$Pb(CH_3COO)_2$ Paper turns PbS (Black)

$Cd(CH_3COO)_2$ Paper turns CdS (yellow)

Note \Rightarrow Sulphide salts of Cr^{+3} , Al^{+3} and Mg^{+2} do not exist in aq. solution because they readily hydrolyse.



Test based on ppt.

